



Car Seat Recalls/Defects & Safety Notices - Revised 4/20/2022

Ensure you are looking at the most recent list! Scan the code (left) using a smartphone QR app.

This printed list includes child restraints manufactured after 1/1/2012, with the most recent addition(s) shaded gray. Information is subject to change, so always verify with manufacturer. Find this list under Resources at www.saferideneews.com. This recall list format was originally developed by the WA State Safety Restraint Coalition and is currently maintained by Safe Ride News Publications.

4moms

888-614-6667

4moms.com

Infant Seat

Self-installing Car Seat made 7/1/16-10/31/16. **Problem:** Hooks that lock the carrier to the base may stick or fail to attach. Until replaced, double check proper locking into base by pulling up on carrier handle; or install carrier without base. **Call 888-614-6667 or visit 4moms.com/recalls**

Aidia, Inc.

(No Recalls)

Angel Guard

(See Merritt Manufacturing)

Aprica

888-927-7422

(See Graco)

aprica.com

Aria Child

888-569-7288

(See Goodbaby)

Baby Jogger, LLC

800-241-1848

babyjogger.com

RF-Only Seats

- **City GO Infant Seat** Models BJ64510, BJ64529;
- **City GO Infant Car Seat Base** Models BJ80400, BJ61500;
- **City Mini Car Seat Stroller System** Model BJ72510;
- **Vue Lite Car Seat Stroller System** BJ70411, BJ70424, BJ70431

Made 11/3/14 - 4/30/15.

Problem: Incorrect/missing information on labels/instruction book may decrease correct use of seat increasing risk of injury. **Call: 800-241-1848.**

Baby Trend

800-328-7363

babytrend.com

Combination Seat

3-in-One Hybrid LX model FB48417 made 7/14/16 sold only at Wal-Mart & model FB58181 made 7/23/16 sold only at Military Exchanges. **Problem:** In a crash, center adjuster may detach in harnessed mode if child weighs more than 40 pounds. To determine if your seat requires free replacement **Call: 800-328-7363**

3-in-One TrendZ Fastback Models FB60070, FB60408 made 10/11-/13.

Problem: Buckle may become difficult to unlatch or become stuck in latched position. **Call: 800-328-7363** for new buckle. Effectiveness of buckle to restrain child is NOT affected.

Bergeron

(No Recalls)

800-371-2778

adaptivemail.com

Britax

888-427-4829

www.britaxusa.com

RF-Only Seats

BOB B-Safe 35 Models E9LT34A, E9LT34C, E9LT35X, EXLT34A. All made 11/1/15 through 5/31/17.

Problem: Center tab on chest clip can break, presenting choking hazard to infant. **Call: 833-474-7016.**

B-Safe Travel System Models

beginning S91: 4900, 5400, 5200

- S921900
- S01635200

Made 10/1/14 - 7/1/15. **Problem:** Car seat carry handle may crack or fracture while carrying it, causing risk of injury to child. Do not carry by handle until fixed. Recall does not affect seat when used in vehicle or on stroller. **Call: 800-683-2045.**

B-Safe 35

Problem #1 of 2: Models

- Beginning E1A: 183F, 185M, 185P, 186R, 203F, 205M, 205P, 206X, 206Z, 207E
- Beginning E9LU: 65V, 66X, 66Z, 67D, 67E. EXA185M
- Beginning S020: 63600, 63700.
- Beginning S03803: 400, 500, 700, 800, 900
- Beginning S04: 144400, 144500, 144600, 145000, 402800, 884200, 884300, 975600, 978900
- Beginning S0: 5260200, 6020300, 6020400, 6020500, 6020600, 6020700, 6020800, 6020900, 6147100
- S921800

Center tab on chest clip can break presenting choking hazard to infant. **Call: 833-474-7016.**

Problem #2 of 2: Models

- EXLU65M and those
- Beginning E9L: U65M, U65P, U63F, U66R, S63F.

Made 10/1/14 - 7/1/15. Car seat

carry handle may crack/fracture while carrying it, causing risk of injury to child. Do not carry by handle until fixed. Recall does not affect seat when used in vehicle or on stroller. **Call: 800-683-2045.**

B-Safe 35 Elite

Problem #1 of 2: Models

- Beginning E1A2: 15T, 15U, 16P, 21Q, 25C, 25U, 26L
- Beginning E9L: S5, 1Q, 6C, 6L, 7F, 7G, 7H
- EXA216L
- Beginning S0: 1298600, 2063800, 2063900, 2064000, 4281200, 4281300, 4628500, 6018800, 6020000, 6020200
- S923700

All made 11/1/15-5/31/17. Center tab on chest clip can break presenting choking hazard to infant. **Call: 833-474-7016**

Problem #2 of 2: Models beginning E9L: 55T, 56P, 55U, 66C, 65U. Made 10/1/14 - 7/1/15. Car seat carry handle may crack/fracture while carrying it, causing risk of injury to child. Do not carry by handle until fixed. Recall does not affect seat when used in vehicle or on stroller. **Call: 800-683-2045.**

Convertible Seats

Advocate 70-G3, Boulevard 70-G3 and Pavilion 70-G3 models

begin "E9L" J91A, E91M, J91S, J92E, J93P, J93S, K91A, K31A, K31Q, K32D, K32Z, K33Q, L11A, L11Q, L12D, L12Z, G81A, G83N, G83P, G83X, G83Y, L21A, L23P, L23Y made 6/1/12 - 8/31/12.

Problem: Child chewing on HUGS chest pad may bite off small piece, presenting choking hazard. **Call: 888-427-4829** for new HUGS chest pads. New HUGS pads are marked "PP" under harness webbing.

Advocate ClickTight Models

E9LT86F, E1A135Q, E9LT86G, E9LT85Q, E9LT86A, E9LT86H, E9LT85S, E1A015Q, E1A016A, and E1A016H made 8/1/14 - 7/29/15.

Problem: Red harness adjuster button may remain in release position preventing harness from locking. Continue using seat if harness button does not stick & harness remains tensioned. **Call: 888-427-4829.**

Boulevard ClickTight models

beginning "E1A" 013Q, 016A, 016H, 135Q, LT85Q, or beginning "E9LT" 85Q, 85S, 86A, 86F, 86G, 86H made 8/1/14 - 7/29/15.

Problem: Harness adjuster button (red) may remain down in release position and prevent harness from locking. Continue using seat if harness button does not stick and harness remains tensioned. All registered owners will receive a repair kit automatically. **Call: 888-427-4829.**

Marathon ClickTight models

E1A116L, E9LT76P, E9LT71Q, E9LT76N, E9LT76B, E9LT75R, E9LT76L, E1A006B, E1A005R and EXA116L made 8/1/14 - 7/29/15. **Problem:** Red harness adjuster button may remain in release position preventing harness from locking. Continue using seat if harness button does not stick and harness remains tensioned. **Call: 888-427-4829.**

BubbleBum

(No Recalls)

800-969-6586

bubblebum.co/us

Carfoldio

(No Recalls)

mifold.com

CARES

(No Recalls)

800-299-6249

kidsflysafe.com

Chicco

(No Recalls)

877-424-4226

chiccousa.com

CLEK Inc.

866-656-2462

clekinc.com

RF-Only Seats

Liing Model LG19U1 and

Liingo Model LGO20U1

Problem #1 of 2: On units made prior to 9/15/2020, the canopy support can break under pressure, posing a choking hazard if small pieces are ingested by a child.

Call: 866-656-2462 for a stronger canopy stay; it's safe to use the CR until fixed if canopy is intact.

Problem #2 of 2: On units made prior to 2/22/2021, labels on the seat padding and insert may detach, posing a choking hazard if ingested by a child.

Call: 866-656-2462 for replacement pad/insert; it's safe to use the CR until fixed if labels are intact.

CLEK Inc. (continued)

866-656-2462

clekinc.com

Convertible Seats

Filo Model FL15-FO19 and

Foonf Model FO12-FO19 made prior to 5/21/21.

Problem: Pieces of foam cushion from under the padding can be picked loose by the child, posing a choking hazard if ingested. **Call:** 866-656-2462 for a plastic insert; monitor child behavior until the repair kit is applied.

Columbia Medical

(See Inspired By Drive)

Combi USA, Inc.

800-992-6624

combiusa.com

Convertible Seats

Coccoro Model 8220 made 1/1/09-7/31/16. **Problem 1 of 2:** When installed forward-facing and secured with vehicle LAP-ONLY belt, excessive force may be transferred to the car seat occupant in a crash increase-ing their risk of injury.

(Recall does not affect use of seat when installed rear-facing. If installed forward-facing with lap/shoulder belt and lock-off or lower anchors and tether). **Call:** 888-232-3294. **Problem #2 of 2: Coccoro** Model 818220 made 1/1/09 - 12/31/12. Plastic button on harness does not pass breaking strength (when tested independently from child restraint).

Call: 844-697-1690 for new harness.

Zeus 360 made 2/1/09 - 5/31/12.

Problem: Plastic button on harness does not pass breaking strength (when tested independently from child restraint).

Call: 844-697-1690 for new harness.

BabyRide RF-only car seat (no base), model #378099, manufacture dates 5/1/2016—8/31/2019.

Problem: The webbing of the 1-inch harness adjuster strap fails to meet the breaking strength requirement of FMVSS 213. Since the segment of this strap that falls *behind* the A-lock adjuster is part of the overall harness, this strength issue could potentially cause an infant to be improperly restrained in a crash.

IMPORTANT NOTES: This model is branded by its manufacturer, Nania. During a portion of the recall period, units labeled as Nania BabyRide were imported into the U.S. through a now

defunct distributor, Team-Tex America. Therefore, Nania and/or Team-Tex may be prominent on the CR, packaging, and ordering information, whereas the brand Combi (the most recent importer that's responsible for this recall), may not be indicated.

BabyRide is a CR with no base that states no minimum weight (allowing use "from birth") and is sold exclusively through institutional distributors, so most units in circulation have been provided to caregivers through distribution programs. These programs are advised to check inventory and notify clientele.

Contact: Email

customerservice@combiusa.com; no remedy was announced as of print date.

Compass

(See Tomy)

Convaid

(See Etac)

844-876-6245

etac.us.com

Cosco

(See Dorel)

CYBEX

877-242-5676

cybex-online.com

Convertible Seat

Cybex Sirona M models

518000385, 518002153, 518000387, 518002145, 518002149, 518002151, and 519000211, made 11/3/17 through 8/31/18.

Problem: It's possible for a child to pick pieces of foam from the headrest padding, which could be an ingestion/choking hazard.

Call: 877-242-5676 to get a manufacturer-provided tape kit with instructions for how to apply it to the lower edge of the headrest's EPS foam. The car seat is safe to use while awaiting the fix, provided caregivers understand that they must monitor children to ensure they do not pick at foam.

Diono 855-242-5676 diono.com

All-in-1 Seats

Radian RXT, Radian R100, Radian R120, Rainier, Olympia, & Pacifica made

11/25/2013-9/25/2017. **Problem:**

The seat may not adequately protect a child *when used in harnessed mode & installed forward-facing*. Children using seat in booster mode are not affected. Forward-facing children using the harness, who weigh more than 65 pounds (with any installation method) **MUST** use top tether. For vehicles not equipped with tether anchor, use seat in booster mode. Forward-facing children using the harness who weigh 65 pounds or less whose seat is installed with a lap-only belt in vehicles without a tether anchor **MUST** install repair kit. **Call:** 855-215-4951.

Booster Seat

Cambria 2 booster model numbers 31200-US-01, 31201-US-01, and 31202-US-01 made 9/5/2020, through 11/30/2020, and used in highback mode.

Problem: The headrest may crack and possibly separate from the booster during a crash. Diono will provide a replacement seat back. The replacement seat back does not have padding; the instructions will say to transfer the original padding to the replacement seat back and how to attach the seat back to the booster base. **Call:** 855-463-4666.

Dorel Juvenile Group

(Cosco, Eddie Bauer, Safety 1st, Maxi-Cosi)

800-544-1108

djgusa.com

RF-Only Seats

Comfy Carry Model IC123 FSM

made 5/1/11-4/25/12. **Problem:**

Some seats were sold without lower LATCH attachment strap. **Call:** 877-416-8111 for new base with LATCH. Until new base is received installed with a seat belt.

OnBoard 35 Model IC124 FSM made

5/1/11-4/25/12. **Problem:** Some seats were sold without lower LATCH attachment strap. **Call:** 877-416-8111 for replacement base with LATCH. Until new base is received installed with a seat belt.

Convertible Seats

Maxi-Cosi Pria 70, Pria 85

and **Pria 85 Max**, all dates since Jan 1, 2019. **Problem:** The car seat allows more forward head movement than allowed by FMVSS 213 *when used by a child weighing more than 65 pounds and installed forward-facing*

using a lap-only belt and no tether. (CRs properly used in rear-facing mode are not affected.) The recall fix from Dorel is new instructions and labeling that limit use of the CR to a maximum child size of 65 pounds or 49 inches for any forward-facing installation. Owners using or intending to use the CR for a child over 65 pounds may request a free Maxi-Cosi Rodi Sport booster. Until fixed, follow these new instructions. Always attach the tether when used forward-facing, whenever possible.

Call: 877-657-9546 or email pria85recall@djgusa.com.

Booster Seat

Babideal Model "Storm,"

#BC901BPXL, made 2/28/19 and sold at Family Dollar stores. **Problem:** Some required safety labels are missing, and some labels present are for non-vehicle boosters only (wrongly indicating the booster should not be used in vehicles). **Call:** 877-657-9546 to get a new fabric cover with appropriate labels.

Etac (incl. Convaid, R82)

844-876-6245

etac.us.com

A non-recall, consumer advisory:

R82 Quokka, made May 2019.

Problem: Some units, upon unboxing, have been found to have a broken RF belt guide.

Call: Consumers with this problem should call 844-876-6245 to order a free fix kit with instructions.

Evenflo

800-233-5921

evenflo.com

RF-Only Seats

Embrace35 made 12/1/11-5/31/13. Models:

- 30711365,
- Beginning 31511: 040, 323, 400, 398
- 3151953, 31521138, 46811205, 46811237
- Beginning 48111: 200, 215, 215A, 218, 234, 235, 235A, 11462,
- Beginning 484: 11391, 11391D, 11392, 11504, 11504d
- Beginning 52: 911307A, 921040,
- Beginning 55: 311138, 311238, 311292

Problem: Harness buckle may become stuck in latched position making it difficult to remove child.

Call: 800-490-7591 for new buckle or online buckle.evenflo.com

Evenflo (continued)

800-233-5921

evenflo.com

Convertible Seats

- **Momentum 65 (LX and DLX)** Models beginning "385" made 3/4/13-8/26/13.
- **Sure Ride DLX** Models beginning with "371" made 6/20/12-10/17/13.
- **Titan 65** Models beginning "371" made 6/20/12-10/17/13.

Problem: Harness buckle may become stuck in latched position making it difficult to remove child. For new buckle **Call:** 800-490-7591.

Combination Seats

- **Chase, Chase LX & Chase Select** Models beginning "306" made 8/23/11-3/3/14
- **Chase LX and DLX** Models beginning "329" made 8/23/11-3/3/14.
- **Secure Kid (LX, DLX, 100, 300, and 400 models)** beginning "308" made 12/13/11-3/3/14.
- **Symphony 65, 65E3 (LX and DLX)** Models beginning "345" or "346" made 10/2/12-8/26/13.
- **Maestro and Maestro Performance** models beginning "310" made 8/22/11-10/17/13 have buckle recall (below) AND **Maestro** Model numbers beginning "310" made 11/24/09-4/9/10 also have problem #2.

Problem#1 of 2: Harness buckle may become stuck in latched position making it difficult to remove child. **Call:** 800-490-7591 to order new buckle.

Problem #2 of 2: In a crash, crack may form at front of seat causing child to not be properly restrained. **Call:** 800-233-5921 for reinforcement kit. Children weighing less than 40 lbs. should use another seat until repaired; those weighing more than 40 lbs. may continue use *only* as a booster until repaired.

Evolve Models 34411700 and 344117421 *when used with harness* made before 2/9/16. **Problem:** Child may reach button and loosen harness. If child loosens harness stop using seat until remedy is installed. **Call:** 800-233-5921.

Transitions Models *when used with harness* 34411686, 34411695, and 34411029, made 12/18/14-1/29/16. **Problem:** Child may reach button and loosen harness. If child loosens harness stop using seat until remedy is installed. **Call:** 800-233-5921.

Booster Seats

Big Kid Model 30911173AD, 3091967AD, 30911118AD & 30911120D. **Problem:** Between 8/6/12-9/18/12 a small number of seats --meeting all crashworthiness standards--but intended for display--were incorrectly shipped to institutional customers. Affected units have a label stating: "Display Only," Not intended for sale" on back of headrest. **Call:** 800-233-5921 for instruction manual, registration card & label.

E-Z-On Products (No Recalls)
800-323-6598 ezonpro.com

GoBooster (No Recalls)
888-327-4336 gobooster.com

Goodbaby USA (See Evenflo)
844-543-2020 gbchildusa.com

Graco 800-345-4109 gracobaby.com

RF-Only Seats

- **SnugRide & SnugRide Classic Connect** made 3/1/11-5/31/13 and
- **SnugRide 30 & SnugRide Classic Connect 30** made 7/1/10-1/31/13 and
- **SnugRide 35 & SnugRide Classic Connect 35** made 5/1/11-1/31/13 and
- **SnugRide Click Connect 40** made 6/1/12 - 12/31/12 and
- **Aprica A30** made 7/1/11-4/30/12.

Problem: Some harness buckles can become stuck in latched position. Effectiveness of buckle to restrain child is NOT affected. For new buckle **Call:** 877-766-7470.

Convertible Seats

- **Classic Ride 50** made 10/1/11-9/30/13.
- **Cozy Cline, Toddler Safe Seat-Step 2** made 1/1/06 - 4/30/10.
- **My Ride 70** made 5/1/12-7/31/13.
- **My Size 70, Size4Me 70, Headwise 70, Headwise 70 with Safety Surround** made 1/1/12-7/31/13 and 8/3/13 as some made after production end date of were made with old buckles.
- **Ready Ride 70** made 10/01/10 - 9/30/13.
- **Smart Seat, Smart Seat with Safety Surround** made 12/1/10-9/30/13 and 10/9/13,

12/25/13, 1/10/14 (some made after the end date of production were made with the old buckles).

Problem: Harness buckles can become stuck in latched position. Effectiveness of buckle to restrain child is NOT affected. **Call:** 877-766-7470.

Classic Ride model 1812930 made 3/1/14-2/28/15. **Problem:** Label missing information on instruction book location. For new label **Call:** 800-345-4109.

Comfort Sport models 1794333, 1813040 made 3/1/14-2/28/15. **Problem** Label missing information on instruction book location. **Call:** 800-345-4109.

Extend2Fit model 1954477 made 11/27/15-1/20/16. **Problem:** Recline label affixed to wrong location may result in infant too upright or toddler too reclined. To confirm unit is affected by recall, also check the recline labels (including the one (identifying recline positions 1-6); on each side of seat, they should all be one language (English one side, Spanish the other. If they are not in same language, the unit is subject to this recall. **Call:** 800-345-4109

My Ride 65, My Ride 65 with Safety Surround made 4/1/09-7/31/13 and 9/30/13.

- 1908152 made 7/23/14 - 7/27/14
- 1813074 made 6/20/14 - 7/27/14
- 1872691 made 5/16/14 - 8/1/14
- 1853478 made 7/11/14 - 7/27/14
- 1871689 made 7/5/14 - 7/24/14
- 1877535 made 5/26/14 - 7/27/14
- 1813015 made 7/3/14 - 7/24/14
- 1794334 made 5/20/14 - 7/15/14

Problem #1: Some harness buckles can become stuck in latched position. Effectiveness of buckle to restrain child is NOT affected. **Call:** 877-766-7470 for new buckle.

Problem #2: An additional problem for the models listed above and model #1908152 (5/20/14-7/15/14) affects **My Ride 65 only**. If the fabric tag on the harness says "2014/06," the harness webbing does not meet breaking strength and must be replaced. **Call:** 800-345-4109 for a new harness. Seat may continue to be used while waiting for replacement.

Ready Ride Models 1924519, 1923520 made 3/1/14-2/28/15. **Problem:** Label does not show instruction book location. (Also see buckle recall earlier on this list.)

Call: 800-345-4109

All-in-1 Seats

Milestone Models 1910130, 1923980, 1926538, 1926539 made

7/9/15-10/9/15. **Problem:** Labels do not have required wording about how to install seat with LATCH or seat belt per FMVSS 213. Recall does not affect safety performance. **Call:** 800-345-4109 for new label.

Combination Seats

- **Argos 70 & Argos 70 Elite** made 5/1/11-7/31/13.
- **Nautilus, Nautilus Elite, Nautilus Plus**, made 10/1/07-7/31/13 (and 8/19/13, as some units made on this day also have the recalled buckles).

Problem: Harness buckle can become stuck in latched position. Effectiveness of buckle to restrain child is NOT affected. **Call:** 877-766-7470.

Booster Seats

Turbo Booster Models:

- 1963973 made 3/8/16-4/2/16
- 1963974 made 12/22/15-3/30/16
- 1963975 made 12/22/15-3/17/16
- 1963976 made 2/17/16-3/24/16
- 1967886 made 1/13/16-4/5/16
- 1975173 made 3/29/16

Problem: Owner's manual omits instruction to prevent seat from becoming projectile by buckling it when not in use. Seat is still effective to restrain child. **Call:** 800-345-4109.

Harmony

877-306-1001 harmonyjuvenile.com

Big Boost Deluxe made 11/1/15-6/24/17. **Problem:** In a crash, seat belt may cause excessive force on child's chest increasing risk of injury. **Call:** 877-306-1001.

Hauck/iCoo (No Recalls)

hiccapop (No Recalls)
833-442-2266 hiccapop.com

IMMI (See Safe Guard)
317-896-6612 imminet.com

InspiredByDrive (No Recalls)
Formerly Columbia Medical
800-454-6612 inspiredbydrive.com

Jané (No Recalls)
415-824-12371 janeus.com

Jeffco Fibres (No Recalls)
508-673-1001 jeffcofibres.com

Kiddy 678-377-3309 (No U.S. website)

Combination Seats

World Plus Combination Seat
model 51-100WP made 2/1/12-10/5/13. **Problem:** Buckle tongue on shield may not fully engage leaving child unrestrained. *Affects seat only when used with shield* (not as booster; use this seat as booster only). **Call:** 855-925-4339 for refund.

Kids Embrace (No Recalls)
866-947-3287

Kids II (aka Ingenuity) (No Recalls)
770-551-0442 kidsii.com

Lamazé (See Tomy)

LaRoche Brothers (No Recalls)
(See Jeffco Fibres)

Learning Curve (See Tomy)

Lil Fan (No Recalls)
317-804-9160 lilfan.com

Lilly Gold (See Triple Play)

Little Tikes (No Recalls)
800-321-0183 littletikes.com

Maxi-Cosi (See Dorel)

Merritt Manufacturing
317-409-0148 eztether.com

Car Bed

Angel Ride car beds made 8/8/19-10/24/19. **Problem:** Harness may not be sewn correctly at the buckle attachment point
Call: 317-409-0148 for a harness replacement kit.

Mia Moda, Inc. (No current recalls)
866-642-6632 miamodainc.com

Mifold (See Carfoldio)

Nania (See BabyRide under Combi)

Nuna (No Recalls)
855-686-2872 nunababy.com

Orbit Baby
877-672-2229 orbitbaby.com

RF-Only Seats

Orbit Baby Car Seat Bases G2
Bases model ORB822000 with Batch #A0840, A0860 or A0880 made 3/20/13-7/20/13.

Problem: The base's StrongArm knob may detach or spin without tightening base, preventing proper installation. Register seat at Orbit website, then **Call:** 877-672-2220 for StrongArm knob repair kit. If seat is not tightly secured, install without base until repaired.

Peg Pérego (No Recalls)
800-671-1701 pegperego.com

Phil&Teds (See Goodbaby)

Porsche (Contact Britax)

R82 (See Etac)
844-876-6245 etac.us.com

Recaro
888-973-2276 us.recaro-cs.com

Convertible Seats

- **ProRide** all models beginning with 332.01 made 4/9/10-6/9/15.
- **Performance Ride** all models beginning 33301 made 1/15/13-6/9/15. **Problem:** Tether may detach from car seat during crash increasing risk of injury to child or other occupants. **Call:** 866-628-4750

Safe Traffic System (No Recalls)
847-233-0365 safetrafficsystem.com

SafeGuard (No Recalls)
800-586-7839 safeguardseat.com

Safeline Kids (See Tripleplay)

Safety 1st (See Dorel)

Sentry Baby Products (No Recalls)
719-212-6016 sentrybabyproducts.com

Simple Parenting (No Recalls)
862-240-1755
happykidssmartparents.com

Snug Seat (See Etac)

Snugli
800-374-3603 snugli.com

All-in-One Seats

Snugli All-in-One models beginning "346" made 10/2/12 - 8/26/13. **Problem:** Harness buckle be difficult to release and could cause risk to child in an emergency.
Call: 800-490-7591.

Booster Seats

Snugli Booster models beginning "308" made 12/13/11 - 3/3/14. **Problem:** Harness buckle may be difficult to release and could cause risk to child in an emergency.
Call: 800-490-7591.

Summer Infant (No Recalls)
800-268-6237 summerinfant.com

Team-Tex America

(See Combi BabyRide)

Thomashilfen (No Recalls)
866-870-2122 thomashilfen.com

Tomy International (No Recalls)
800-704-8697
http://www.recall.rc2.com/recalls_Past.html

Triple Play (No current recalls)

Uppababy (No Recalls)
781-413-3000 uppababy.com

Urbini (See Goodbaby)

WAYB
888-924-9292 wayb.com

Forward-Facing Seat

Pico travel car seat models made 2/1/19 - 8/23/19, and model number ending in -001. **Problem:** Aluminum tubular frame on headrest can potentially detach from seat, leading to an increased risk of injury in a crash. **Call:** customer service at 888-924-9292. Go to www.wayb.com/repair for instructions to ship product for repair.