



# Car Seat Recalls/Defects & Safety Notices - Revised 12/19/24

Ensure you are looking at the most recent list! Scan the code (left) using a smartphone camera or app. This printed list includes recalls on any child restraint manufactured after 1/1/2015 (most recent addition shaded gray). Note: Since most car seats expire in fewer than 10 years from the date of manufacture, some car seats on this list may no longer be covered by the recall notice; rather than be repaired, they should be replaced and properly discarded. Contact the manufacturer for all recall details.

Find this list under Resources at [www.saferideneews.com](http://www.saferideneews.com). This recall list format was originally developed by the WA State Safety Restraint Coalition and is currently maintained by Safe Ride News Publications.

## 4moms

888-614-6667 [4moms.com](http://4moms.com)

### Infant Seat

**Self-installing Car Seat** made 7/1/16-10/31/16. **Problem:** Hooks that lock the carrier to the base may stick or fail to attach. Until replaced, double check proper locking into base by pulling up on carrier handle; or install carrier without base. **Call:** 888-614-6667 or visit [4moms.com/recalls](http://4moms.com/recalls)

**Note:** These units are now all expired.

## Angel Guard

(See Merritt Manufacturing)

## Aprica

(See Graco; all units expired)

## Aria Child

(See Goodbaby)

## Baby Jogger, LLC

800-241-1848 [babyjogger.com](http://babyjogger.com)

### RF-Only Seats

- **City GO Infant Seat** Models BJ64510, BJ64529;
- **City GO Infant Car Seat Base** Models BJ80400, BJ61500;
- **City Mini Stroller System** Model BJ72510;
- **Vue Lite Stroller System** BJ70411, BJ70424, BJ70431

Made 11/3/14 - 4/30/15.

**Problem:** Incorrect/missing information on labels/instruction book may decrease correct use of seat increasing risk of injury.

**Call:** 800-241-1848.

**Note:** These units are all expired.

## Baby Trend

800-328-7363 [babytrend.com](http://babytrend.com)

### Combination Seat

**Hybrid 3-in-1 Combination Booster** (Desert Blue, from Walmart)

Model: #FB49E14A 12/21

Made on: 12/6/2021

**Problem:** The LA strap, if frayed, may not meet the strength required by FMVSS 213 and FMVSS 209.

Registered owners will automatically receive a replacement LA attachment and instructions. Until received, install CR using a seat belt.

If a seat belt *cannot* be used, inspect the original LA strap carefully for fraying or other damage and, if in good condition, use it only until it can be replaced.

**Call** 800-328-7363 for information or search Recalls and Safety Notices at [www.babytrend.com](http://www.babytrend.com).

**Hybrid 3-in-1 LX** model FB48417 made 7/14/16 sold only at Wal-Mart & model FB58181 made 7/23/16 sold only at Military Exchanges. **Problem:** In a crash, center adjuster may detach in harnessed mode if child weighs more than 40 pounds. **Call:** 800-328-7363 (NOTE: This car seat in harness mode is now expired.)

## Bergeron

(No Recalls) 800-371-2778 [adaptivemail.com](http://adaptivemail.com)

## Britax

888-427-4829 [www.britaxusa.com](http://www.britaxusa.com)

### RF-Only Seats

**B-Safe 35 and B-Safe 35 Elite**

#### **Recall #1 of 2:**

Made 11/1/15 through 5/31/17.

**BOB B-Safe 35** (w/stroller system)

- Beginning E9LT3: 4A, 4C, 5X
- EXLT34A.

**B-Safe 35** Models

- Beginning E1A: 183F, 185M, 185P, 186R, 203F, 205M, 205P, 206X, 206Z, 207E
- Beginning E9LU: 65V, 66X, 66Z, 67D, 67E. EXA185M
- Beginning S020: 63600, 63700.
- Beginning S03803: 400, 500, 700, 800, 900
- Beginning S04: 144400, 144500, 144600, 145000, 402800, 884200, 884300, 975600, 978900
- Beginning S0: 5260200, 6020300, 6020400, 6020500, 6020600, 6020700, 6020800, 6020900, 6147100
- S921800

**B-Safe 35 Elite** Models

- Beginning E1A2: 15T, 15U, 16P, 21Q, 25C, 25U, 26L
- Beginning E9L: S5, 1Q, 6C, 6L, 7F, 7G, 7H
- EXA216L, S923700
- Beginning S0: 1298600, 2063800, 2063900, 2064000, 4281200, 4281300, 4628500, 6018800,

6020000, 6020200

**Problem:** Center tab on chest clip can break, presenting choking hazard.

**Call:** 833-474-7016.

**Note:** These units are now all expired.

#### **Recall #2 of 2:**

Made 10/1/14 through 7/1/15

**B-Safe 35** (w/stroller system) models beginning S91 plus: 4300, 4500, 4700, 4900, 5400, 5200 **as well as** S921900 and S01635200

**B-Safe 35** Models

- EXLU65M
- Beginning E9L plus: U65M, U65P, U63F, U66R, V15M, V15P, V13F.

**B-Safe 35 Elite** Models beginning E9LS plus: 55T, 56P, 55U, 66C, 65U.

**Problem:** Car seat carry handle may crack/fracture while being carried. Do not carry by handle until fixed. Recall does not affect seat when used in vehicle or on stroller.

**Call:** 800-683-2045.

**Note:** These units are now all expired.

### Convertible Seats

**Advocate 70-G3, Boulevard 70-G3 and Pavilion 70-G3** models

begin "E9L" J91A, E91M, J91S, J92E, J93P, J93S, K91A, K31A, K31Q, K32D, K32Z, K33Q, L11A, L11Q, L12D, L12Z, G81A, G83N, G83P, G83X, G83Y, L21A, L23P, L23Y made 6/1/12 - 8/31/12.

**Problem:** Child chewing on HUGS chest pad may bite off small piece, presenting choking hazard.

**Call:** 888-427-4829

**Note:** These units are now all expired.

#### **ClickTight Convertible models:**

Made 8/1/14 - 7/29/15

**Advocate ClickTight** Models beginning E9LT plus: 86F, 86G, 86A, 86H, 85Q, 85S and beginning E1A plus: 135Q, 015Q, 016A, and 016H.

**Boulevard ClickTight** models beginning E1A plus: 013Q, 016A, 016H, 135Q, LT85Q, and

beginning E9LT plus: 85Q, 85S, 86A, 86F, 86G, 86H

**Marathon ClickTight** models E1A116L, E9LT76P, E9LT71Q, E9LT76N, E9LT76B, E9LT75R, E9LT76L, E1A006B, E1A005R and EXA116L

**Problem:** Harness adjuster button (red) may remain down in release position and prevent harness from

locking. Continue using seat while awaiting repair only if harness button does not stick and harness remains tensioned.

**Call:** 888-427-4829.

**Note:** Most units are now expired.

### All-in-One Seat

**One4Life Slim ClickTight** models

E1D197A, E1D197B, E1D197F, E1D197G; made July 10-12, 2024

**Problem:** The child weight limit for using the LA attachment to install the CR rear facing is incorrectly stated on labels and in owner's manuals. The RF LA attachment child weight limit should be 35 pounds.

**Call:** 888-427-4829

## BubbleBum

(No Recalls) 800-969-6586 [bubblebum.co/us](http://bubblebum.co/us)

## Carfoldio

(No Recalls) [mifold.com; out of business](http://mifold.com; out of business)

## CARES

(No Recalls; airplane only) 800-299-6249 [kidsflysafe.com](http://kidsflysafe.com)

## Century

(No Recalls) [centurybaby.com](http://centurybaby.com)

## Chicco

(No Recalls) 877-424-4226 [chiccousa.com](http://chiccousa.com)

## CLEK Inc.

866-656-2462 [clekinc.com](http://clekinc.com)

### RF-Only Seats

**Liing** Model LG19U1 and

**Liingo** Model LGO20U1

**Problem #1 of 2:** On units made prior to 9/15/2020, the canopy support can break under pressure, posing a choking hazard if small pieces are ingested by a child.

**Call:** 866-656-2462 for a stronger canopy stay; it's safe to use the CR until fixed if canopy is intact.

**Problem #2 of 2:** On units made prior to 2/22/2021, labels on the seat padding and insert may detach, posing a choking hazard if ingested.

**Call:** 866-656-2462 for replacement pad/insert; it's safe to use the CR until fixed if labels are intact.

## Convertible Seats

**Filo** Model FL15-F019 and

**Foonf** Model FO12-F019

**Made:** prior to 5/21/21.

**Problem:** Pieces of foam cushion from under the padding can be picked loose by the child, posing a choking hazard if ingested.

**Call:** 866-656-2462 for a plastic insert; monitor child behavior until the repair kit is applied.

## Booster Seats

**Olli** Model OL12U2 made 1/20/20 through 5/10/22

**Ozzi** Model OZ11U2 made 3/1/2020 through 5/10/22.

**Problem:** Diagram for lap-and-shoulder belt routing not on label.

**Call:** 866-656-2462 for a new label; refer to owner's manual for belt use instructions until label replaced.

## Columbia Medical

(See Inspired by Drive)

## Columbus Trading-Partners U.S.A, Inc.

(See CYBEX)

## Combi USA, Inc.

### Convertible Seats

**Coccoro** Model 8220

Made 1/1/09 through 7/31/16.

**Problem #1 of 2:** When installed FF and secured with vehicle LAP-ONLY belt, excessive force may be transferred to the car seat.

(Note: Recall does not affect rear-facing mode or when the car seat is installed forward facing with a lap/shoulder belt and lock-off or lower anchors and tether.)

**Contact:** Combi no longer has U.S. support

**Problem #2 of 2:** Made 1/6/09 - 12/5/12. Harness webbing fails to meet minimum strength requirements.

**Email:** customerservice@combiusa.com

**Note:** Problem #2 units are now all expired.

**BabyRide** RF-only car seat (no base), model #378099, manufacture dates 5/1/2016—8/31/2019.

**Problem:** The webbing of the 1-inch harness adjuster strap fails to meet the breaking strength requirement of FMVSS 213. Since the segment of this strap that falls *behind* the A-lock adjuster is part of the overall harness, this strength issue could potentially cause an infant to be improperly

restrained in a crash.

**IMPORTANT NOTES:** This model is branded by its manufacturer, Nania. During a portion of the recall period, units labeled as Nania BabyRide were imported into the U.S. through a now defunct distributor, Team-Tex America. Therefore, Nania and/or Team-Tex may be prominent on the CR, packaging, and ordering information, whereas Combi, the most recent importer, may not be indicated (but is responsible). BabyRide is a CR with no base that states no minimum weight (allowing use "from birth"), sold exclusively through institutional distributors, so most units in circulation have been provided to caregivers through distribution programs. These programs are advised to check inventory and notify clientele. (Check carefully for expiration; most units are expired.)

**Contact:** Email customerservice@combiusa.com; no remedy announced as of print date.

**Convaid** (See Etac)  
844-876-6245 etac.us.com

**Cosco** (See Dorel)

**CYBEX**  
877-242-5676 cybex-online.com

### RF-Only Seats

**Aton** made 3/29/17-1/4/20.

**Aton Q** made 3/13/17-1/3/20.

**Aton M** made 3/17/18-11/1/20.

**Aton 2** made 3/29/17-10/27/20.

**Cloud Q** made 7/6/17-10/20/20.

**Problem:** The webbing for the one-inch central harness adjuster strap may fray too easily; when frayed, the webbing fails to meet strength requirements of FMVSS 213. The recall kit has a new harness adjuster strap (with end not folded/sewn) and instructions for replacement. (Owners who previously incurred a cost for replacement due to this problem should call, as well.)

**Call:** 877-242-5676

### Convertible Seat

**Cyberx Sirona M** models 518000385, 518002153, 518000387, 518002145, 518002149, 518002151, and 519000211, made 11/3/17 through 8/31/18.

**Problem:** It's possible for a child to pick pieces of foam from the headrest padding, which could be an ingestion/choking hazard.

**Call:** 877-242-5676 to get a manufacturer-provided tape kit with instructions for how to apply it to

the lower edge of the headrest's EPS foam. The car seat is safe to use while awaiting the fix, provided caregivers understand that they must monitor children to ensure they do not pick at foam.

**Diono** 855-242-5676 [diono.com](http://diono.com)

### All-in-1 Seats

**Radian RXT, Radian R100, Radian R120, Rainier, Olympia, & Pacifica** made 11/25/2013-9/25/2017.

**Problem:** The seat may not adequately protect a child *when used in harnessed mode & installed forward-facing*. Children using seat in booster mode are not affected. Forward-facing children using the harness, who weigh more than 65 pounds (with any installation method) MUST use top tether. For vehicles not equipped with tether anchor, use seat in booster mode. Forward-facing children using the harness who weigh 65 pounds or less whose seat is installed with a lap-only belt in vehicles without a tether anchor MUST install repair kit.  
**Call:** 855-215-4951.

### Booster Seat

**Cambria 2** booster model numbers 31200-US-01, 31201-US-01, and 31202-US-01 made 9/5/2020, through 11/30/2020, and used in highback mode.

**Problem:** The headrest may crack and possibly separate from the booster during a crash. Diono will provide a replacement seat back. The replacement seat back does not have padding; the instructions will say to transfer the original padding to the replacement seat back and how to attach the seat back to the seat.  
**Call:** 855-463-4666.

## Dorel Juvenile Group

(Cosco, Eddie Bauer, Safety 1st, Maxi-Cosi)  
800-544-1108 [djgusa.com](http://djgusa.com)

### RF-Only Seats

The base of the following models, all made February 2023 or earlier, with a self-retracting system for the LA attachment. Note: Does not include CRs with similar names that have non-retracting LA attachments.

#### Maxi-Cosi:

**Coral XP** (#IC313) made 5/1/20-2/28/23. (Also, see next recall.)

**Mico XP** (#IC336, #IC38) made 9/1/20-2/28/23.

**Mico XP Max** (#IC337) made 9/1/20-2/28/23.

**Mico Luxe+**, (#IC370) made

9/1/20-2/28/23.

**Any replacement base with self-retracting LA attachment** (#IC335) made 5/1/20-2/28/23.

#### Safety 1st:

**onBoard 35 Secure Tech** (#IC351) made 5/1/20-2/28/23.

**Any replacement base with self-retracting LA attachment (Secure Tech)** pre-2/23/23

Also, the recalled base may be included in the following travel systems: Gia XP, Zelia 2 Max, Tayla, Tayla XP, Adorra, Mara XT, and Lila CP (Canada).

**Problem:** The LA attachment system may not hold the base properly. Owner's will be sent a new base. Until received, install the CR with the base (or baseless) using the vehicle seat belt only.

**Call:** Contact Dorel at 877-657-9546 or send an email to [RetractableLatchRecall@djgusa.com](mailto:RetractableLatchRecall@djgusa.com)

**Maxi-Cosi Coral XP** #IC313, all dates. (Also, see prior recall.)

**Problem:** The inner carrier cannot be installed in the car without the use of a supplemental device (the outer carrier) and therefore the CR fails to meet FMVSS 213 requirements, including those regarding installation and dynamic performance. Until a refund or replacement has been issued, the CR's inner carrier may be installed while properly attached to the outer carrier, per all instructions.

**Call:** 877-657-9546 or email [CoralXPRecall@djgusa.com](mailto:CoralXPRecall@djgusa.com).

### Convertible Seats

**Maxi-Cosi Pria 70, Pria 85 and Pria 85 Max,**

Made Jan. 1, 2019–Sept. 8, 2021

**Problem:** The car seat allows more forward head movement than allowed by FMVSS 213 *when used by a child weighing more than 65 pounds and installed forward-facing using a lap-only belt and no tether*. (CRs properly used in rear-facing mode are not affected.) The recall fix from Dorel is new instructions and labeling that limit use of the CR to a maximum child size of 65 pounds or 49 inches for any forward-facing installation. Owners using or intending to use the CR for a child over 65 pounds may request a free Maxi-Cosi Rodi Sport booster. Until fixed, follow these new instructions. Always attach the tether when used forward-facing, whenever possible.  
**Call:** 877-657-9546 or email [pria85recall@djgusa.com](mailto:pria85recall@djgusa.com).

## Booster Seat

**Babideal** Model "Storm," #BC901BPXL, made 2/28/19 and sold at Family Dollar stores. **Problem:** Some required safety labels are missing, and some present labels are for non-vehicle boosters only (wrongly indicating the booster should not be used in vehicles). **Call:** 877-657-9546 to get a new fabric cover with appropriate labels.

## Etac (incl. Convaid, R82)

844-876-6245 [etac.us.com](http://etac.us.com)  
**R82 Quokka** made May 2019. **Problem:** A non-recall, consumer advisory: Some units, upon unboxing, have been found to have a broken RF belt guide. **Call:** Consumers with this problem should call 844-876-6245 to order a free fix kit with instructions.

## Evenflo

800-233-5921 [evenflo.com](http://evenflo.com)

### Convertible Seats

**Momentum 65 (LX and DLX)** Models beginning "385" made 3/4/13-8/26/13.  
**Sure Ride DLX** Models beginning with "371" made 6/20/12-10/17/13.  
**Titan 65** Models beginning "371" made 6/20/12-10/17/13.  
**Problem:** Harness buckle may become stuck in latched position making it difficult to remove child. For new buckle **Call:** 800-490-7591. **(Note:** These units are now all expired.)

**Titan 65, made 5/20/22:** An issued recall applied to only one unit, which had missing labels. The CR was returned to Evenflo and destroyed. No other CRs in the field are expected to have this problem.

### Combination Seats

**Evolve** # 34411700 and 344117421 Made before 2/9/16. (Affects harness mode only.)  
**Problem:** Child may reach button and loosen harness. If child loosens harness stop using seat until remedy is installed.  
**Call:** 800-233-5921.  
**Note:** These units are now all expired.

**Transitions** #34411686, 34411695, and 34411029  
Made 12/18/14-1/29/16. (Affects harness mode only.)

**Problem:** Child may reach button and loosen harness. If child loosens harness stop using seat until remedy is installed.

**Call:** 800-233-5921.

**Note:** These units are now all expired.

## E-Z-On Products (No Recalls)

800-323-6598 [ezonpro.com](http://ezonpro.com)

## Goodbaby USA

(See Evenflo and Cybex)

## Graco

800-345-4109 [gracobaby.com](http://gracobaby.com)

### Convertible Seats

**Classic Ride** model #1812930 made 3/1/14-2/28/15. **Problem:** Label missing information on instruction book location.

**Call:** 800-345-4109.

**Note:** These units are now all expired.

**Comfort Sport** models 1794333, 1813040 made 3/1/14-2/28/15. **Problem:** Label missing information on instruction book location.

**Call:** 800-345-4109.

**Note:** These units are now all expired.

**Extend2Fit** model 1954477 made 11/27/15-1/20/16.

**Problem:** Recline label affixed to wrong location may result in infant too upright or toddler too reclined. To confirm unit is affected by recall, also check the recline labels (including the one identifying recline positions 1-6); on each side of seat, they should all be one language (English one side, Spanish the other). If they are not in same language, the unit is subject to this recall.

**Call:** 800-345-4109

**Ready Ride** Models 1924519, 1923520 made 3/1/14-2/28/15. **Problem:** Label does not show instruction book location. (Also see buckle recall earlier on this list.)

**Call:** 800-345-4109

**Note:** These units are now all expired.

### All-in-1 Seats

**Milestone** Models 1910130, 1923980, 1926538, 1926539 made 7/9/15-10/9/15. **Problem:** Labels do not have required wording about how to install seat with LATCH or seat belt per FMVSS 213. Recall does

not affect safety performance.

**Call:** 800-345-4109 for new label.

## Booster Seats

**Turbo Booster** Models:

- 1963973 made 3/8/16-4/2/16
- 1963974 made 12/22/15-3/30/16
- 1963975 made 12/22/15-3/17/16
- 1963976 made 2/17/16-3/24/16
- 1967886 made 1/13/16-4/5/16
- 1975173 made 3/29/16

**Problem:** Owner's manual omits instruction to prevent seat from becoming projectile by buckling it when not in use. Seat is still effective to restrain child. **Call:** 800-345-4109.

## Harmony

877-306-1001 [harmonyjuvenile.com](http://harmonyjuvenile.com)

**Big Boost Deluxe** made 11/1/15-6/24/17. **Problem:** In a crash, seat belt may cause excessive force on child's chest increasing risk of injury. **Call:** 877-306-1001. (Check for expiration.)

**Hauck/iCoo** (No Recalls)

**hiccipop** (No Recalls)  
833-442-2266 [hiccipop.com](http://hiccipop.com)

**IMMI** (See Safe Guard)  
317-896-6612 [imminet.com](http://imminet.com)

**InspiredByDrive** (No Recalls)  
Formerly Columbia Medical  
800-454-6612 [inspiredbydrive.com](http://inspiredbydrive.com)

## JD E-Commerce America Limited

**Marainbow** (made any date, also sold under Joybuy Express) AS WELL AS "materially similar products that may suffer from the noted defects." (Find an image that's representative of affected products and a list of product names, including Portable Infant Safe Seat, at [www.saferidenews.com/unsafe-products](http://www.saferidenews.com/unsafe-products).)

**Problem:** The device does not comply with FMVSS 213 in several ways. Its design prohibits it from being installed properly, and installation labels display incorrect instructions. It may also lack an owner's manual and/or recall registration card.

**Call:** 302-426-4543 for a refund. Consumer will be required to prove that the product has been destroyed by sending images to [overseas-service@jd.com](mailto:overseas-service@jd.com).

Owners may also contact NHTSA at 888-327-4236 (reference NHTSA Campaigns #22C-007 and #22C-008). **Editor's Note:** Due to the integral nature of some of the defects, as well as the seriousness of the risk, **DO NOT USE this product.** It should be replaced with a 213-compliant CR that's suitable for the child.

## Joybuy Express

(See J.D. E-Commerce America Limited, the recall listed immediately prior.)

**Kiddy** (No U.S. website/phone; all units expired)

**Kids Embrace** (No Recalls)  
866-947-3287  
[kidsembrace.com](http://kidsembrace.com)

**Lilly Gold** (See Triple Play)

**Maxi-Cosi** (See Dorel)

**Merritt Manufacturing**  
317-409-0148 [eztether.com](http://eztether.com)

### Car Bed

**Angel Ride** car beds made 8/8/19-10/24/19. **Problem:** Harness may not be sewn correctly at the buckle attachment point  
**Call:** 317-409-0148 for a harness replacement kit.

**Mifold** (See Carfoldio)

**Nania** (See BabyRide under Combi)

**Nuna**  
855-686-2872 [nunababy.com](http://nunababy.com)

### Convertible Seats

**Rava** all units made 7/16/16-10/25/23 with padding that does not cover the front harness adjuster. **Problem:** If debris has dropped down into the front harness adjuster area and collected on the locking mechanism, it can prevent the teeth from clamping on the adjuster strap so the harness may not stay tight. Owners will be supplied with a cleaning kit, care instructions, and a new seat pad that will protect this area of the CR. If the harness is functioning properly and staying snug on the child, the CR can continue to be used, following all instructions.  
**Call:** 855-686-2891 or visit [www.nunababy.com/usa/recalls-rava1](http://www.nunababy.com/usa/recalls-rava1).

**Orbit Baby** [orbitbaby.com](http://orbitbaby.com)

**Peg Perego** (No Recalls)

800-671-1701 [pegperego.com](http://pegperego.com)

**Phil&Teds** (No Recalls)

**Porsche** (Contact Britax)

**Portable Child/Infant Seat**

(See J.D. E-Commerce America Limited)

**R82** (See Etac)

844-876-6245 [etac.us.com](http://etac.us.com)

**Recaro**

888-973-2276 [us.recaro-cs.com](http://us.recaro-cs.com)

### Convertible Seats

**ProRide** all models beginning with 332.01 made 4/9/10-6/9/15.

**Performance Ride** all models beginning 33301 made 1/15/13-6/9/15.

**Problem:** Tether may detach from car seat during crash increasing risk of injury to child or other occupants.

**Call:** 866-628-4750

**Note:** These units are now all expired.

**Safe Traffic System** (No Recalls)

847-233-0365 [safetrafficsystem.com](http://safetrafficsystem.com)

**SafeGuard** (No Recalls)

800-586-7839 [safeguardseat.com](http://safeguardseat.com)

**Safeline Kids** (See Tripleplay)

**Safety 1st** (See Dorel)

**Sentry Baby Products** (No Recalls)

OOB; contact info no longer available.

**Simple Parenting** (No Recalls)

844-477-9539 [www.doona.com/en-US](http://www.doona.com/en-US)

**Snug Seat** (See Etac)

**Snugli**

OOB; Contact Evenflo. All units now expired.

**Summer Infant** (No Recalls)

800-268-6237 [summerinfant.com](http://summerinfant.com)

**Team-Tex America**

(See Combi BabyRide)

**Thomashilfen** (No Recalls)

866-870-2122 [thomashilfen.com](http://thomashilfen.com)

**Tomy International** (No Recalls)

800-704-8697

**Triple Play** (No current recalls)

646-484-8112 [lillygold.com](http://lillygold.com)

**Uppababy** (No Recalls)

781-413-3000 [uppababy.com](http://uppababy.com)

**Urbini** (See Goodbaby)

**WAYB**

888-924-9292 [wayb.com](http://wayb.com)

### Forward-Facing Seat

**Pico** travel car seat

Made 2/1/19 through 8/23/19

Model number ending in -001.

**Problem:** Aluminum tubular frame on headrest can potentially detach from seat, leading to an increased risk of injury in a crash.

**Call:** 888-924-9292. Go to [www.wayb.com/repair](http://www.wayb.com/repair) for instructions to ship product for repair.